

R A D I O N I C S

D8112E/E1 Program Record Sheet

for the D5200 Programmer

Date _____

Subscriber Name _____ Premises Phone _____

Address _____

City / State / ZIP _____

Installer Name _____ Subscriber Contact _____

Account Number _____ Record Name _____

Control Panel Location _____

Control Panel Phone # _____ Aux Power Current Load _____ mA

AC Voltage _____ VAC Battery Voltage _____ VDC Earth Ground Location _____

Transformer Location _____ RJX38X _____

Bell / Siren Locations _____

Recommended Zone Codes

24 Hour Zone Codes

	Trouble & Restoral	Trouble no restoral	No trouble no restoral	Local no reports
Fire Zones				
Standard	3181	3141	1141	1541
Priority	3183	3143	1143	1543
Panic & Holdup (Audible)				
Normally closed	2171	2131	1131	1531
+ invisible zone	2175	2135	1135	1535
Normally open	3171	3131	1131	1531
+invisible zone	3175	3135	1135	1535
Panic & Holdup (Silent)				
Normally closed	2151	2111	1111	1511
+ invisible zone	2155	2115	1115	
Normally open	3151	3111	1111	1511
+invisible zone	3155	3115	1115	
	OP/CL restoral	OP/CL no restoral	NO OP/CL restoral	NO OP/CL no restoral
Independent Zone Controls				
Standard	3271	3231	3471	3431
Priority	3273	3233	3473	3433

Controlled (Burglary) Zone Codes

	Trouble & Restoral	Trouble no restoral	No trouble no restoral	Local no reports
Perimeter Zones				
Delay (norm. closed)	6771	6731	5731	1731
+swinger shunt	6772	6732	5732	1732
Delay (norm. open)	7671	7631	5631	
+swinger shunt	7672	7632	5632	
Instant (norm. closed)	6571	6531	5631	
+swinger shunt	6572	6532	5632	
Instant (norm. open)	7571	7531	5631	1731
+swinger shunt	7572	7532	5632	1732
Glass Break Zone	3171	3131	1131	1531
+swinger shunt	3172	3132	1132	1532
Window Foil	8571	8531	5531	1731
+swinger shunt	8572	8532	5532	1732
Interior Zones				
Delay (norm. closed)	6371	6331	5331	1731
+swinger shunt	6372	6332	5332	1732
Delay (norm. open)	7271	7231	5231	
+swinger shunt	7272	7232	5232	
Instant (norm. closed)	6171	6131	5131	
+swinger shunt	6172	6132	5132	
Instant (norm. open)	7171	7131	5131	1731
+swinger shunt	7172	7132	5132	1732

AUX (8112E1 only)

3 ABCD Keys	3.1 AKey	-----	3.3 CKey	-----
	3.2 BKey	-----	3.4 DKey	-----
8 Delay All	Y or N			

Loop

Loop is a utility which is used to perform diagnostic loop testing on the D8112E and D8112E1. The Loop utility is accessed at the 8112E and 8112E1 Product Handler level in the D5200 Programmer, and has no program items. See the *Loop* chapter of the *D8112E/E1 Control/Communicator Program Entry Guide* for more information.

©1992 Radionics, Inc., Salinas, CA, U.S.A. All rights reserved.

™ The Radionics logo is a registered trademark of Radionics, Inc., Salinas, CA, U.S.A.



Radionics™

Radionics, Inc., 1800 Abbott Street
Salinas, CA 93901, U.S.A.
Technical Support: (800) 538-5807

Radionics, 1 Park Gate Close, Bredbury
Stockport, Cheshire, SK6 2SZ, England
Technical Support: (061) 494 0851

MAIN

Primary Central Station	1 Off	Y or N	4 SgRd	Y or N	7 P	-----
	2 Local	Y or N	5 Ack 14	Y or N	8 Ph	-----
	3 CS	[]	6 Ack 23	Y or N		

Additional Phone	9 DTMF	Y or N	12 PhBel	Y or N	14 PhLite	Y or N
	10 BzFail	Y or N	13 2Line	Y or N	15 PhT/R	Y or N
	11 PhSupv	---				

Call Routing	16 Route	[]	17 AltZn	[]
---------------------	----------	-----	----------	-----

Alternate Central Station	18 ACS	[]	20 AP	-----
	19 ASgRd	Y or N	21 APh	-----

Account No./ Supervision	22 Acct	-----	25 ExT/R	Y or N	27 ACRes	Y or N
	23 Tbl	[]	26 DlyRes	Y or N	28 BatSupv	Y or N
	24 Res	[]				

Interrogation/Remote Programming	29 AnsArm	--	30 AnsDis	--	34 Pass	----
---	-----------	----	-----------	----	---------	------

Automatic Test Report	35 Intvl	--	40 TsE	Y or N	45 TsDef	Y or N
	36 Days	Y or N	41 TsAlt	Y or N	46 TsClr	Y or N
	37 Month	Y or N	42 TsStat	Y or N	47 ArmSys	Y or N
	38 50Hz	Y or N	43 TsDis	Y or N		
	39 TsCode	[]	44 TsArm	Y or N		

Arm/Disarm Supervision	48 Open	[]	51 Supv9	Y or N	54 CombID	Y or N
	49 Close	[]	52 Cancel	[]		
	50 ReO/C	Y or N	53 Duress	[]		

Arm/Disarm Combinations	Combo	User Receiver		Combo	User Receiver	
		Name	Display		Name	Display
55 Comb 1	-----		B	62 Comb 8	-----	8
56 Comb 2	-----		C	63 Comb 91	-----	1
57 Comb 3	-----		D	64 Comb 92	-----	2
58 Comb 4	-----		E	65 Comb 93	-----	3
59 Comb 5	-----		F	66 Comb 94	-----	4
60 Comb 6	-----		6	67 Comb 95	-----	5
61 Comb 7	-----		7	68 Comb 96	-----	0

MAIN (continued)

Entry/Exit Delay	69 DlyIn	---	70 DlyOut	---	71 Prewarn	Y or N
Bell Output/Listen-In	72 Bell	--	74 TsBel	Y or N	76 Listen	--
	73 1Ring	Y or N	75 Pulse	Y or N	77 Hush	Y or N
Arming Station	78 MCArm	Y or N	79 ArmLED	Y or N	80 Blink	Y or N
Arming Commands	82 Cmd99	----	84 Cmd2	Y or N	86 Cmd8	Y or N
	83 Cmd1	Y or N	85 Cmd3	Y or N		
Force Arming	87 FAMax	--	89 FA2	Y or N		
	88 FA1	Y or N	90 FA3	Y or N		
Test Commands	91 Cmd41	Y or N	92 Cmd42	Y or N	93 Cmd44	Y or N
Special Commands	94 Cmd47	Y or N	96 Cmd6	Y or N	98 Cmd9	[]
	95 Cmd5	Y or N	97 Cmd7	[]		
Special Alpha Commands	99 ShuntMA	Y or N	101 Clock	Y or N	103 Show	Y or N
	100 ShntPA	Y or N	102 Serv	Y or N	104 OnBat	Y or N
Zone Function Codes	105 Zone1	----	111 Zone4	----	117 Zone7	----
	106 D1	-----	112 D4	-----	118 D7	-----
	107 Zone2	----	113 Zone5	----	119 Zone8	----
	108 D2	-----	114 D5	-----	120 D8	-----
	109 Zone3	----	115 Zone6	----		
	110 D3	-----	116 D6	-----		
Modem & ExRAM (D8112E1 only)	123 16ChDisp	Y or N				