

ARM/DISARM CODES 1-7

LOCATION	PAGE	DESCRIPTION	DATA 1	DATA 2	DATA 3	DATA 4	DEFAULT
000-003	10	USER #1 ARM / DISARM CODE					"1-2-3-4"
004-007	10	USER #2 ARM / DISARM CODE					"15" DISABLED
008-011	10	USER #3 ARM / DISARM CODE					"15" DISABLED
012-015	10	USER #4 ARM / DISARM CODE					"15" DISABLED
016-019	10	USER #5 ARM / DISARM CODE					"15" DISABLED
020-023	10	USER #6 ARM / DISARM CODE					"15" DISABLED
024-027	10	USER #7 ARM / DISARM CODE					"15" DISABLED
028-031	10	"GO TO PROGRAM" ACCESS CODE					"9-7-1-3"

PHONE NUMBERS, ACCOUNT CODES, & FORMATS

032-039	8	PRIMARY PHONE NUMBER DIGITS 1 - 8								"0" DISABLED
040-047	8	PRIMARY PHONE NUMBER DIGITS 9 - 16								"0" DISABLED
048-051	8	PRIMARY ACCOUNT CODE								"0" DISABLED
052	8	PRIMARY FORMAT								"0" DISABLED
053	8	SECONDARY PHONE NUMBER CONTROL								"0" DISABLED
054-061	8	SECONDARY PHONE NUMBER DIGITS 1 - 8								"0" DISABLED
062-069	8	SECONDARY PHONE NUMBER DIGITS 9 - 16								"0" DISABLED
070-073	9	SECONDARY ACCOUNT CODE								"0" DISABLED
074	9	SECONDARY FORMAT								"0" DISABLED

CONTROL & COMMUNICATOR FEATURES

LOCATION	PAGE	DESCRIPTION	DATA	DEFAULT
075	9	ENTRY DELAY TIME (10 SECOND INCREMENTS)		"3" 30 SECONDS
076	9	EXIT DELAY TIME (10 SECOND INCREMENTS)		"6" 60 SECONDS
077	9	SIREN SHUTDOWN / RECYCLE TIME OUT (2 MINUTE INCREMENTS)		"4" 8 MINUTES
078	11	ZONE 1 TYPE		"3" ENTRY / EXIT
079	11	ZONE 2 TYPE		"5" INT FOLLOWER
080	11	ZONE 3 TYPE		"6" INSTANT
081	11	ZONE 4 TYPE		"6" INSTANT
082	11	ZONE 5 TYPE		"6" INSTANT
083	11	ZONE 6 TYPE		"6" INSTANT
084	11	ZONE 1-4 SIREN SELECT		"15" AUDIBLE
085	11	ZONE 5-6 SIREN SELECT		"3" AUDIBLE

LOCATION	PAGE	DESCRIPTION	ZONE ID	EVENT/EXT CODE	DEFAULT
086-087	12	DURESS COMMUNICATOR CODE			"0" DISABLED
088-089	12	AUX 1 COMMUNICATOR CODE			"0" DISABLED
090-091	12	AUX 2 COMMUNICATOR CODE			"0" DISABLED
092-093	12	KEYPAD PANIC COMMUNICATOR CODE			"2 - 0"
094-095	12	TAMPER COMMUNICATOR CODE			"0" DISABLED
096-097	13	DOWNLOAD COMPLETE COMM CODE			"0" DISABLED
098-099	13	AUTOTEST COMMUNICATOR CODE			"0" DISABLED
100-101	13	FAIL TO COMMUNICATE CODE			"0" DISABLED

LOCATION	PAGE	DESCRIPTION	ZONE ID	EVENT/EXT CODE	DEFAULT
102	13	CLOSING COMMUNICATOR CODE		MAN NUMBER	"0" DISABLED
103	13	OPENING COMMUNICATOR CODE		MAN NUMBER	"0" DISABLED
104-105	13	ZONE 1 COMMUNICATOR CODE			"1 - 0"
106-107	13	ZONE 2 COMMUNICATOR CODE			"2 - 0"
108-109	13	ZONE 3 COMMUNICATOR CODE			"3 - 0"
110-111	14	ZONE 4 COMMUNICATOR CODE			"4 - 0"
112-113	14	ZONE 5 COMMUNICATOR CODE			"5 - 0"
114-115	14	ZONE 6 COMMUNICATOR CODE			"6 - 0"
116-117	14	START TEST COMMUNICATOR CODE			"0 - 0" DISABLED
118-119	14	END TEST COMMUNICATOR CODE			"0 - 0" DISABLED
120-121	14	AC POWER LOSS COMMUNICATOR CODE			"0" DISABLED
122-123	14	LOW BATTERY COMMUNICATOR CODE			"0" DISABLED
124	15	TROUBLE COMMUNICATOR CODE		ZONE NUMBER	"0" DISABLED
125	15	ZONE BYPASS COMMUNICATOR CODE		ZONE NUMBER	"0" DISABLED
126	15	RESTORE COMMUNICATOR CODE		ZONE NUMBER	"0" DISABLED
127	15	CANCEL COMMUNICATOR CODE		MAN NUMBER	"0" DISABLED

LOCATION	PAGE	DESCRIPTION	DATA	DEFAULT
128	15	ABORT ENABLE		"0" DISABLED
129	15	KEYPAD PANIC SILENT OR AUDIBLE		"0" AUDIBLE
130	15	NUMBER OF ALARMS FOR SWINGER SHUTDOWN		"0" DISABLED
131	16	AUTO BYPASS/ INSTANT ARMING		"0" DISABLED
132	16	SIREN DRIVER OR VOLTAGE OUTPUT		"0" SIREN DRIVER
133	16	LED EXTINGUISH FEATURE		"0" DISABLED
134	16	NUMBER OF DIAL ATTEMPTS		"8" EIGHT
135	16	POWER UP CONDITION		"0" LAST CONDITION
136	16	POWER UP DELAY		"0" 60 SEC DELAY
137	16	IMMEDIATE RESTORE BY ZONE		"0" DISABLED
138	16	NO ARMING WITH ZONE BYPASSED		"0" DISABLED
139	17	QUICK ARM ENABLE		"0" DISABLED
140	17	FIRE SIREN CUTOFF INHIBIT		"0" RECYCLES
141	17	DOUBLE LINE EXTENDED REPORTING		"0" DISABLED
142	17	SIREN/BELL TEST FEATURE		"0" DISABLED
143	17	SMOKE POWER RESET AND/OR FIRE ALARM VERIFICATION		"1" POWER RESET
144	17	EUROPEAN PULSE DIAL RATIO		"0" DISABLED
145	17	AUXILIARY OUTPUT CONDITION #1		"0" BURGLARY
146	17	AUXILIARY OUTPUT CONDITION #2		"1" FIRE ALARM
147	17	AUXILIARY OUTPUT CONDITION #3		"2" PANIC/DURESS
148	17	AUXILIARY OUTPUT CONDITION #4		"3" ARMED STATE
149	18	INVERTING THE AUXILIARY OUTPUT		"0" HIGH GOING
150	18	DELAY AC POWER LOSS REPORT		"0" DELAYED
151	18	NUMBER OF RINGS TO ANSWER DOWNLOAD CALL		"8" EIGHT RINGS
152	19	NUMBER OF DAYS LEFT UNTIL AUTOTEST		UNDEFINED
153	19	PROGRAM CLOCK, CURRENT MONTH		UNDEFINED
154	19	PROGRAM CLOCK, CURRENT YEAR - TENS DIGIT (1994)		UNDEFINED
155	19	PROGRAM CLOCK, CURRENT YEAR - ONES DIGIT (1994)		UNDEFINED

LOCATION	PAGE	DESCRIPTION	DATA	DEFAULT
156	19	PROGRAM CLOCK, CURRENT DAY OF MONTH - TENS DIGIT		UNDEFINED
157	19	PROGRAM CLOCK, CURRENT DAY OF MONTH - ONES DIGIT		UNDEFINED
158	19	PROGRAM CLOCK, CURRENT HOUR - TENS DIGIT		UNDEFINED
159	19	PROGRAM CLOCK, CURRENT HOUR - ONES DIGIT		UNDEFINED
160	19	PROGRAM CLOCK, CURRENT MINUTE - TENS DIGIT		UNDEFINED
161	20	PROGRAM CLOCK, CURRENT MINUTE - ONES DIGIT		UNDEFINED
162	20	PROGRAM AUTOTEST TIME, HOUR - TENS DIGIT		"0"
163	20	PROGRAM AUTOTEST TIME, HOUR - ONES DIGIT		"0"
164	20	PROGRAM AUTOTEST TIME, MINUTE - TENS DIGIT		"0"
165	20	PROGRAM AUTOTEST TIME, MINUTE - ONES DIGIT		"0"
166	20	PROGRAM AUTOTEST TIME REPORTING INTERVALS		"0"
167	20	ROTATING MAINTENANCE CODES ENABLE		"0" DISABLED
168	20	ROTATING MAINTENANCE CODES - SEED CODE DIGIT 1		"0"
169	20	ROTATING MAINTENANCE CODES - SEED CODE DIGIT 2		"0"
170	20	ROTATING MAINTENANCE CODES - SEED CODE DIGIT 3		"0"
171	20	ROTATING MAINTENANCE CODES - SEED CODE DIGIT 4		"0"
172	20	USER #7 (MAINTENANCE CODE) OPENING REPORT		"0" DISABLED
173	20	USER #7 (MAINTENANCE CODE) CLOSING REPORT		"0" DISABLED
174	20	PROGRAM ZONES 3 THRU 6 FOR NORMALLY CLOSED OPERATION		"0" SUPERVISED
175	20	PROGRAM ZONES 1,2 FOR NORMALLY CLOSED OPERATION		"0" SUPERVISED
176	20	SPLIT REPORT - TAMPER, DOWNLOAD COMPLETE, & AUTOTEST		"0" PHONE #1
177	20	SPLIT REPORT - AC FAILURE, LOW BAT, OPEN/CLOSE, & MAINT OPEN/CLOSE		"0" PHONE #1
178	20	SECONDARY ENTRY DELAY TIME		"0"
179	20	SECONDARY EXIT DELAY TIME		"0"
180	21	LOOP RESPONSE TIME		"0" 500 MS
181	21	AUTOTEST SUPPRESSION		"0"
182	21	FORMAT OVER-RIDE		"0"
183	21	FORMAT OVER-RIDE		"0"
184-185	21	RESERVED		RESERVED
186	21	ZONE 1 SPECIAL CHARACTERISTICS		"14"
187	21	ZONE 2 SPECIAL CHARACTERISTICS		"6"
188	21	ZONE 3 SPECIAL CHARACTERISTICS		"14"
189	21	ZONE 4 SPECIAL CHARACTERISTICS		"14"
190	21	ZONE 5 SPECIAL CHARACTERISTICS		"14"
191	21	ZONE 6 SPECIAL CHARACTERISTICS		"14"
192	21	RESERVED		"14"
193	21	RESERVED		"14"
194	21	RESERVED		"0" DISABLED
195	21	RESERVED		"0" INSTANT
196	22	ANSWERING MACHINE DEFEAT ENABLE		"0" DISABLED
197	22	FORCE ARMING ENABLE		"0" DISABLED
198	22	TIME FOR AUTOMATIC ARMING, HOUR - TENS DIGIT		"2"
199	22	TIME FOR AUTOMATIC ARMING, HOUR - ONES DIGIT		"0"
200	22	TIME FOR AUTOMATIC ARMING, MINUTE - TENS DIGIT		"0"
201	22	TIME FOR AUTOMATIC ARMING, MINUTE - ONES DIGIT		"0"
202	22	AUTOMATIC ARMING ENABLE		"0"

LOCATION	PAGE	DESCRIPTION	DATA	DEFAULT
203	22	DYNAMIC BATTERY TEST		"0"
204	22	DUAL REPORT - TAMPER, DOWNLOAD COMPLETE, & AUTOTEST		"0" PHONE #1
205	23	DUAL REPORT - AC FAILURE, LOW BAT, OPEN/CLOSE, MAINT OPEN/CLOSE		"0" PHONE #1
206	23	DUAL REPORT EVERYTHING		"0"
207	23	CALLBACK PHONE NUMBER CONTROL		"0"
208	24	FORMAT OVER-RIDE		"0"
209	24	FORMAT OVER-RIDE		"0"
210	24	EXIT ERROR COMMUNICATOR CODE		"0"
211	24	RECENT CLOSING COMMUNICATOR CODE		"0"
212-215	24	USER #8 ARM / DISARM CODE		"15" DISABLED
216-219	24	USER #9 ARM / DISARM CODE		"15" DISABLED
220-223	24	USER #10 ARM / DISARM CODE		"15" DISABLED
224-227	24	USER #11 ARM / DISARM CODE		"15" DISABLED
228-231	24	USER #12 ARM / DISARM CODE		"15" DISABLED
232-235	24	USER #13 ARM / DISARM CODE		"15" DISABLED
236-239	24	USER #14 ARM / DISARM CODE		"15" DISABLED
240	24	NUMBER OF DIAL ATTEMPTS TO PHONE #2		"0"
241-243	24	RESERVED		RESERVED
244	25	ZONE #1 SPECIAL CHARACTERISTICS		"8"
245	25	ZONE #2 SPECIAL CHARACTERISTICS		"8"
246	25	ZONE #3 SPECIAL CHARACTERISTICS		"8"
247	25	ZONE #4 SPECIAL CHARACTERISTICS		"8"
248	25	ZONE #5 SPECIAL CHARACTERISTICS		"8"
249	25	ZONE #6 SPECIAL CHARACTERISTICS		"8"
250	25	RESERVED		"8"
251	25	RESERVED		"8"
252	25	AUXILIARY 3 COMMUNICATOR CODE		"0"
253	25	AUXILIARY 3 EXTENDED COMMUNICATOR CODE		"0"
254	25	USER ON SITE COMMUNICATOR CODE		"0"
255	25	CROSS ZONING TIME (MINUTES)		"5"

DOWNLOADING ACCESSIBLE LOCATIONS

LOCATION	PAGE	DESCRIPTION	DATA	DEFAULT
256-263	26	CONTROL PANEL ACCESS CODE		"8 6 0 0 0 0 0 0"
264-271	26	CALLBACK PHONE NUMBER - DIGITS 1 - 8		"0" DISABLED
272-279	26	CALLBACK PHONE NUMBER - DIGITS 9 - 16		"0" DISABLED
280	26	ANSWERING MACHINE DEFEAT		"0" DISABLED
281	26	LOCAL PROGRAMMING LOCKOUT		"0" NOT LOCKED
282	26	CONTROL PANEL SHUTDOWN		"0" CONTROL ON