

## **Overview:**

The PD8 power distribution module converts a single AC or DC input into eight (8) individually fused outputs.

# **Specifications:**

#### Input:

• Handles up to 28VAC/VDC.

### *Outputs:*

• Eight (8) individually fused outputs (fuses are rated @ 3.5 amp up to 5 amp fuses may be used).

#### • Surge suppression.

### Visual Indicators:

• Power output LED indicator.

### Additional Features:

#### • Power ON / OFF switch.


**Board Dimensions (approximate):** 

5.25"L x 3.25"W x 1"H

# **Installation Instructions:**

- 1. Mount PD8 in desired location/enclosure.
- 2. Connect the desired power supply output to terminals marked [INPUT] (Fig. 1A).
- Note: If using DC voltage, left terminal is NEG. (-) and right terminal is POS. (+) (Fig. 1A).
- 3. Measure output voltage before connecting devices. This helps avoid potential damage.
- All terminals with common suffix P "1P, 2P..." are same polarity.
- 4. Set power switch [SW1] to the OFF position.
- 5. Connect each device to terminal pairs 1 to 8, marked [1P-1N thru 8P 8N].
- 6. Fuses rated at 3.5A/250V (Replacement fuses can be rated at 5.0 amp).
- 7. Set power switch [SW1] to the ON position.





Altronix is not responsible for any typographical errors. Product specifications are subject to change without notice.

140 58th Street, Brooklyn, New York 11220 USA, 718-567-8181, fax: 718-567-9056 website: www.altronix.com, e-mail: info@altronix.com, Lifetime Warranty, Made in U.S.A. IIPD8 - Rev. 111704 K17D

