




INSTALLATION INSTRUCTIONS

OVERVIEW


Portable, hand held "Panic" Transmitters are typically used as panic buttons to activate 24-hour "Police Emergency" alarms or 24-hour "Auxiliary" alarms.

The single button transmitter can be activated by pressing anywhere within the "ALERT" box, and holding for one second.

60-458



60-457



light control

Activate the dual button transmitter by pressing both alert boxes at the same time for one second. The light control button is for systems with optional X-10 modules installed (Not investigated by Underwriters Laboratories).

BATTERY POWER

The Single and Dual Button Alert Panic Transmitters are powered by a 3.6 volt Lithium battery (Saft LS3) which should last at least 1 year under normal circumstances.

PROGRAMMING

General guidelines for programming this sensor are:

1. Set the CPU into Program Mode.
2. Trip the panic by pressing the alert box(es) on panic.
3. Set CPU to it's normal operating mode.

NOTE: Refer to the appropriate CPU installation manual for specific instructions for programming this sensor

TESTING

General guidelines for performing a Dealer Sensor Test are:

1. Using appropriate touchpad for the CPU, enter the applicable Dealer Sensor Test code.
2. Trip the panic by pressing the alert box(es) on panic.
3. Note the number of beeps (from the CPU) indicating how much of the RF signal (rounds) from the panic the CPU heard.

FCC NOTICE

This device complies with FCC Rules Part 15. Operation is subject to the following two conditions:

1. this device may not cause harmful interference
2. this device must accept any interference that may be received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by Interactive Technologies, Inc. can void the user's authority to operate the equipment

INSTALLATION INSTRUCTIONS