

Screw-In Lamp Module LM15A

INSTALLATION AND OPERATING INSTRUCTIONS

Unlike conventional X-10 Modules the LM15A does not have any code wheels. You set its code up from an X-10 controller and it then remembers this code, even after a power outage. Because the LM15A remembers its code, you can set it up in any lamp and then move it to its final location (in an outdoor light fixture, for example). Default code is A1.

1. Unscrew your light bulb from its socket and screw the LM15A into the light socket.
2. Screw an **incandescent** light bulb (up to 150W) into the LM15A. Do NOT use with fluorescent lamps! Turn the lamp switch ON.
3. Set any X-10 controller to the House Code you want the LM15A to respond to.
4. To set the Unit Code and House Code from an MC460 Mini Controller, MT522/MT10A Mini Timer, or RT504/HR12A wireless remote:

Plug the controller into the same outlet as the lamp (you can move it later). Press the ON button (corresponding to the Unit Code you want the LM15A to respond to) on the X-10 controller, 3 times, at about 1 second intervals. On the third press the lamp will turn on signifying that the code has been learned. Write your House Code and Unit Code in the box on the label on the LM15A.

5. To set the code from an SC503 Maxi Controller:

Press the number button only, 3 times. The lamp will turn on, on the third press.

The LM15A will now remember this House Code and Unit Code and respond to it from now on (even after a power outage).

To change the code that the LM15A responds to, turn off the power to it, turn it back on, and then repeat the above steps (within 30 seconds of applying power).

- Note 1. You must leave the lamp switch or wall switch on at all times otherwise the LM15A will have no AC power and you won't be able to control it remotely.
- Note 2. The LM15A does not have local control (you cannot turn the light on from its regular switch). If you want this feature, use the LM465 Lamp Module for plug-in lamps, or the WS467 Wall Switch Module for light fixtures.
- Note 3. The LM15A does not respond to bright and dim commands. It does respond to the All Lights On and All Units Off command.
- Note 4. The LM15A can be used indoors or outdoors.
- Note 5. The LM15A is a one-way device. For two-way applications use the LM14A.

Check Out our Web site at:

<http://www.x10.com>

For more information on X-10 products and special promotional offers.

X-10 (USA) INC. LIMITED 1-YEAR WARRANTY

X-10(USA) Inc. warrants X-10 products to be free from defective material and workmanship for a period of one (1) year from the original date of purchase at retail. X-10(USA) Inc. agrees to repair or replace, at it's sole discretion, a defective X-10 product if returned to X-10(USA) Inc. within the warranty period and with proof of purchase.

If service is required under this warranty:

1. Return the defective unit postage prepaid to X-10 (USA) Inc. (see address on back).
2. Enclose a check for \$4.00 to cover postage and handling.
3. Enclose a dated proof of purchase.
4. X-10 is not responsible for shipping damage.
Units to be returned should be packed carefully.
5. For additional warranty information, contact X-10 (USA) Inc.

Your Name
Address

Date Purchased 19..... Store where purchased LM15A-11/98

FROM

X-10 (USA) Inc.
91 Ruckman Rd., Box 420, Closter, NJ 07624-0420

First Name

Last Name

Street Address - No P.O. Box numbers (for U.P.S.)

City

State

Zip

CONTENTS - MERCHANDISE

RETURN POSTAGE GUARANTEED

POSTMASTER: THIS PARCEL MAY BE OPENED FOR POSTAL INSPECTION

X-10 (USA) Inc.
91 Ruckman Rd., Box 420,
Closter, NJ 07624-0420

Mini Timer MT522/MT10A

A Controller, Timer and Alarm Clock all in one! Programs up to 4 modules to go on and off at specific times, twice a day. Controls 8 modules instantly. Dims lights too.

Maxi Controller SC503

Lets you control up to 16 X-10 Modules at the touch of a button from anywhere in the house. Dims lights too!

Mini Controller MC460

Lets you control up to 8 X-10 Modules at the touch of a button from anywhere in the house. Dims lights too!

2-Way Home Control Interface CM11A

Set up from an IBM compatible PC to control up to 256 X-10 Modules. ActiveHome software & cable included.

Thermostat Set-Back TH2807

Automatically sets-back your central heating/air conditioning. Mounts on the wall under your existing thermostat and plugs into an Appliance Module.

Telephone Responder TR551

Lets you control up to 10 lights and appliances from any outside touch-tone phone.

Wireless Remote Control System RC5000

Lets you control 16 X-10 modules from inside or outside your home. Can also dim and brighten Lamp Modules and Wall Switch Modules. Works with the HR12A PalmPad Remote and X-10 RF Wall Switches (RW684, RW694, RW724).

Lamp Module LM465

Can be Dimmed and Brightened from any X-10 Controller. Responds to "All lights on". Rated for 300 W. Incandescent only. *2-Way version LM14A.*

Appliance Module - AM486/AM466

Two pin polarized (AM486) or 3 pin grounded (AM466). For controlling an air conditioner, TV, stereo, etc. anywhere in the home. Rated 15A for heaters, coffee pots etc.; 1/3 H.P. for motors; 400W for TVs; 500W for lamps. *2-Way versions available AM14A (2 pin), AM15A (3 pin).*

Wall Switch Module WS467

For controlling important indoor and outdoor security lights. Replaces your existing wall switch and installs like a regular dimmer. Dimmed/brightened from any X-10 Controller. Rated 500W incandescent only.

3 - Way Wall Switch Module WS4777

For controlling a light which is controlled by two switches. Same features as WS467.

Split Receptacle Module SR227

Replaces existing wall outlet. The top outlet functions like an Appliance Module, the bottom one is a regular outlet. Rated 15A. Controls ANYTHING which normally plugs into a regular AC outlet.

Universal Module UM506

Isolated contact relay and beeper. Can be set for momentary or continuous operation. Not compatible with DS7000 and DC8700 security systems.